

Model *aSENSE™ - GH*

Carbon dioxide transmitter for Green House Installation

PRODUCT DESCRIPTION

Model *aSENSE™ - GH* is an all-digital, low-cost transmitter for installation in the climate zone.

aSENSE™ - GH measures both temperature and carbon dioxide concentration in the ambient air, transforms the data into digital output signals and sends these values to a comprehensive system.

The special coated PCB and extra dust/water protection filter, makes *aSENSE™ - GH* suited for all kinds of greenhouses, mushroom farms, incubators and similar environments.



FEATURES

- State-of-the-art non-dispersive infrared (NDIR) technology to measure carbon dioxide gas
- Maintenance free in normal applications
- Membrane covered sample chamber resulting in a stable, reliable and highly accurate carbon dioxide sensor
- Reliable and accurate built-in NTC thermistor for measuring temperature
- Fully coated PCB together with a special filter equipped housing makes *aSENSE™ - GH* perfectly resistant towards dust and humidity
- 2 x programmable mixed sensor analogue outputs 0/2-10 VDC and/or 0/4-20 mA for connection to remote central computer.
- OUT1 0 - 3 000 pm CO₂ = 4 - 20 mA
- OUT2 0 - 50 °C = 4 - 20 mA
- Optional RS485 digital interface to PC and advanced control network systems

APPLICATIONS

Carbon dioxide is a necessity to all forms of life. It is a vital parameter in the production of all kinds of plant species, bacteria, chicken etc. A natural application for *aSENSE™ - GH* is therefore to supervise and/or control the climate in e. g. *greenhouses, mushroom farms, agricultural, horticultural and medical incubators* based on CO₂ concentration and temperature. SenseAir model *aSENSE™ - GH* is especially suited for installation in these and similar environments since it measures both temperature & carbon dioxide concentration in one single unit. Both are very important parameters when trying to achieve an optimum growth.

Integrated complimentary humidity sensor is available as option.

The two-in-one function reduces the installation cost by minimizing the total number of boxes and wirings needed!

aSENSE™ - GH transmitter for Green House Installation

Technical Specification *

General Performance

| | |
|--|--|
| Compliance with | EMC directive 89/336/EEC RoHS directive 2002/95/EG |
| Operating Temperature Range ¹ | 0 - 50 °C |
| Storage Temperature Range | -20 to +70 °C |
| Operating Humidity Range | 0 to 95% RH (non-condensing) |
| Warm-up Time | 1 min. (@ full specs) □ 15 minutes |
| Sensor Life Expectancy | > 15 years |
| Maintenance Interval | no maintenance required ^{2,3} |
| Self Diagnostics | complete function check of the sensor |
| Status LED Indicators | yellow = maintenance support, red = relay closed |
| Display | 4 Digits, 7 segments LCD with ppm / °C / % indicator |
| Pushbuttons ⁴ | offer a selection of installation support, calibration and operation functions |

Electrical/Mechanical

| | |
|-----------------------------------|--|
| Power Input | 24 VAC/VDC±20%, 50-60 Hz (half-wave rectifier input) |
| Power Consumption | ≤ 3 Watts average |
| Wiring Connections | max 1,5 mm ² wires |
| Main terminal block | screw terminals |
| Digital/Analog inputs block | spring load terminals |
| UART connector | 5-pin, 2.54 mm pitch, slide connector |
| Dimensions without housing | 9.7 x 6.1 x 1.9 cm (L x W x D) |

Outputs

| | |
|---|---|
| Analog ⁵ | |
| Protection | PTC fuse (auto reset) on signal return <i>M</i> , short-circuit safe |
| Output limits | MIN & MAX limits may be individually set to all outputs |
| Linear outputs OUT1 & OUT2 | 0/2-10 VDC R _{OUT} < 100 OHM, R _{load} > 5k OHM (0/1-5 VDC optional) 0/4-20 mA R _{load} < 500 OHM |
| Linear output OUT4 | 0-10 VDC R _{OUT} < 100 OHM, R _{load} > 5k OHM |
| D/A Resolution | 10 bits, 10 mV / 0.016 mA |
| D/A Conversion Accuracy | voltage mode: ± 2% of reading ± 50 mV current loop: ± 2% of reading ± 0.3 mA |
| ON/OFF | |
| Relay (OUT3) | isolated N.O., 1mA/5V up to 1A/50VAC/24VDC. |
| Open collector OUT4 | in ON/OFF mode: max 0.5A/55VDC (halfwave rectifier for AC) |
| UART Serial com port | |
| Protocol | SenseAir protocol (see <i>comprot 0700xx rev 3_04.pdf</i>) ⁷ PC-interface |
| RS232 UART cable with sliding contact and driver (model A232 Cable) | |
| PC User Interface Program | UIP version 4.0 (or higher) ⁶ |
| RS485 network com. | (accessory -485) RS485 terminal slide-on port, Modbus option |
| LonWorks™ network com. | (accessory -LON) LonWorks™ add-on PCB |

- Note 1: Lower temperature operation range can be reached by adding a box heater assembly.
- Note 2: In normal IAQ applications. Some industrial applications may require an annual zero gas purge, which automatically recalibrates the CO₂ sensor
- Note 3: For -RH models, in applications with elevated temperatures and high humidity levels the relative humidity probe calibration may have to be maintained.
- Note 4: Different menus exist for different models. Push-buttons are available only in models having a LCD.
- Note 5: The specifications are valid for the output load connected to ground *G0* or common signal return *M*.
- Note 6: Free download from SenseAir's home page www.senseair.com
- Note 7: For more information, please contact SenseAir AB

* Can be changed without notice



SenseAir AB, Box 96, SE-820 60 Delsbo, Sweden
Phone: +46-(0)653-71 77 70 · Fax: +46-(0)653-71 77 89
E-mail: senseair@senseair.se · Home page: www.senseair.com